


L500 Installation Components & Layout

The L500 fertigation system can be installed into all most any irrigation system with AC power at or near the location.



L500 Capacities

- L500A - .5gph
- L500B - 1.6gph
- L500C - 3.0gph



Flow sensor and injection valve can be install up 100ft away

Up to 50ft away

Flow sensor

Injection valve

Irrigation Line

Foot valve

The flow sensor and injection valve can be installed into any size line from 1" to 12" with a tee or a saddle.

A tank can be installed at ground level or below ground up to 50 ft. away

A tank can be installed next to the system if it is installed in a room or in a valvebox below the pump

Drawing Not to Scale

